

ART. 619

		PROGRAM			
					
		00 MANUAL			
AlMg 5 5356 - Ø 1,0mm	Argon	01			1/1 ÷ 3/7
AlMg 5 5356 - Ø 1,2mm	Argon	02			1/1 ÷ 4/4
AlMg 5 5356 - Ø 1.6mm	Argon	03			1/1 ÷ 4/1
FE - Ø 0.8mm	Argon+CO2 20%	04		1/1 ÷ 2/6	2/7 ÷ 4/3
FE - Ø 0.8mm	CO2 100%	05	1/1 ÷ 2/4	2/5 ÷ 4/4	
FE - Ø 1.0mm	Argon+CO2 20%	06		1/1 ÷ 3/4	3/5 ÷ 4/8
FE - Ø 1.0mm	CO2 100%	07	1/1 ÷ 2/5	2/6 ÷ 4/8	
FE - Ø 1.2mm	Argon+CO2 20%	08		1/1 ÷ 3/3	3/4 ÷ 4/8
FE - Ø 1.2mm	CO2 100%	09	1/1 ÷ 2/4	2/5 ÷ 4/8	
FE - Ø 1.6mm	Argon+CO2 2%	10		1/1 ÷ 2/8	3/1 ÷ 4/8
FE - Ø 1.6mm	CO2 100%	11	1/6 ÷ 2/2	2/3 ÷ 4/8	
Inox - Ø 0.8mm	Argon+CO2 2%	12	1/1 ÷ 2/5	2/6 ÷ 3/8	
Inox - Ø 1.0mm	Argon+CO2 2%	13	1/1 ÷ 1/8	2/1 ÷ 4/4	
Inox - Ø 1.2mm	Argon+CO2 2%	14	1/1 ÷ 1/7	1/8 ÷ 4/6	
FC (Metal) FE - Ø 1.2mm	Argon+CO2 20%	15		1/1 ÷ 2/6	2/7 ÷ 4/8
FC (Basic) FE - Ø 1.2mm	Argon+CO2 20%	16		1/1 ÷ 3/3	3/4 ÷ 4/8
FC (Rutil) FE - Ø 1.2mm	Argon+CO2 20%	17		2/3 ÷ 3/1	3/2 ÷ 4/8